


# ASE LMR/IRIDIUM CROSSLINK

## CROSSLINK *ANY LMR RADIO* TO IRIDIUM PTT



ASE-9575P-VEH

ASE-9575P  
-BAGDOCK

For team communication using standard land-mobile radio communication the ASE LMR/IRIDIUM CROSSLINK is unparalleled in allowing rapid, intuitive communication services in concert with current equipment already in the field.

# ASE LMR/IRIDIUM CROSSLINK

## CROSSLINK *ANY LMR RADIO* TO IRIDIUM PTT



PELICAN CASE OPTIONAL





**GLOBAL PTT TO LMR PTT  
- ANYWHERE ON EARTH-**



With the strength of the Iridium PTT network combined with the ASE LMR/IRIDIUM CROSSLINK your teams will have incredibly comprehensive access to situational awareness across your entire spectrum of 'in field' assets as well as headquarters/control stations.

# ASE LMR/IRIDIUM CROSSLINK

## CONFIGURE *YOUR* CROSSLINK



### PN: ASE-LMR/PTT X-LINK SYSTEM INCLUDES:



**ASE-9575P-BAGDOCK: Standard/Push to Talk Docking Station**  
 - includes palm/speaker mic, 3M (10ft) magnetic mount GPS/IRID antenna, travel bag, DC power cord, and user manual - does NOT include 9575 phone



**ICRI-ASE01: LMR/PTT X-LINK Interface Cable**  
 - interface cable from ICRI-2P to ASE Dock



**C-AT ICRI-2P: ICRI Radio Interoperability Gateway/Bridge**  
 - ICRI Radio Interoperability Gateway System can be used to interconnect portable or land mobile radios via the Iridium satellite network - anywhere in the world



**C-AT ICRI-RA01: ICRI Radio Interoperability Radio Interface Cable**  
 - ICRI Radio Interface cable to interconnect portable or land mobile radios to the C-AT ICRI System - Call ASE to specify your radio model

### OPTIONAL SYSTEM COMPONENTS:



**C-AT ICRI-BAT: ICRI Radio Battery Pack**  
 - rechargeable external battery pack for ICRI main unit



**ASE-MNT-X2: Vehicle Mount**  
 - includes palm/speaker mic, vehicle RAM mount with 3" arm



**ASE-DMA7: GPS/IRID Antenna**  
 - includes industrial grade antenna with 22FT (7M) antenna cable

# ASE LMR/IRIDIUM CROSSLINK

## CONFIGURE *YOUR* DEPLOYMENT



# of Building/Fixed  
Install kits


ASE-9575P-HQ-P

- \_\_\_\_\_ 12m (40 ft) ASE-FA12
- \_\_\_\_\_ 20m (66 ft) ASE-FA20
- \_\_\_\_\_ 40m (131 ft) ASE-AA511-40
- \_\_\_\_\_ 70m (230 ft) ASE-AA511-70



# of Vehicle kits

ASE-9575P-VEH



# of ICIR Crosslink kits

ASE-LMR/PTT X-LINK



# of In Field/  
Personal kits

ASE-9575-BAGDOCK